

7.2.3.10.e. replace central adjuster cover

Project: B103	Rev.: 03	Date: 2017-02-22 in progress	Pages: 1 of 4	Saved: 22.02.2017	Sign:
Done by: HG	7.2.3.10.e Service instruction to replace iZi Modular central adjuster cover rev03 2017 01 10.docx				

Service to be done by retailer		
What do you need:		
Item number	L2001235 Central adjuster cover	
Tools	hexagonal wrench M4	
	Wire cutter	
Remarks	When the old button is present, replace the button with service manual 7.2.3.10.c and service set L2001237	Old version New version L2001237 

1. Execute safety check when you finish the service instruction.
2. Place seat on clean surface to prevent scratches.

7.2.3.10.e. replace central adjuster cover

Project: B103	Rev.: 03	Date: 2017-02-22 in progress	Pages: 2 of 4	Saved: 22.02.2017	Sign:
Done by: HG	7.2.3.10.e Service instruction to replace iZi Modular central adjuster cover rev03 2017 01 10.docx				

No.	Action
A1	Preparation Partly remove fabric and foam  Unscrew M4 screw  Slide cover to the front 
A2	Cut central adjuster cover with cutter Do not damage belt!  

7.2.3.10.e. replace central adjuster cover

Project: B103	Rev.: 03	Date: 2017-02-22 in progress	Pages: 3 of 4	Saved: 22.02.2017	Sign:
Done by: HG	7.2.3.10.e Service instruction to replace iZi Modular central adjuster cover rev03 2017 01 10.docx				

B1	Slide cover over belt  Pull strap through gap 	
B1	Place button in good position 	Check correct position of the button 
C1	and insert screw through both holes  Replace fabric (tight around central adjuster cover) 	
D1	Safety check!	

7.2.3.10.e. replace central adjuster cover

Project: B103	Rev.: 03	Date: 2017-02-22 in progress	Pages: 4 of 4	Saved: 22.02.2017	Sign:
Done by: HG	7.2.3.10.e Service instruction to replace iZi Modular central adjuster cover rev03 2017 01 10.docx				

Press the button and adjust the harness.



Release the button and pull slow.



The button must directly return in the original position.

There is no slip of the harness allowed after releasing the button.